

Cabinets

Floor cabinets and wall cupboards are manufactured from stainless steel according to customer needs. The standard dimensions are found in the product data sheet. For both cabinet models, the height of shelves can be adjusted in 50 mm increments and additional shelves can be ordered if needed. The SST shelf options are solid plate, perforated plate and grate shelves.

The cabinet doors have a two-layer structure, and can be equipped with a regular or serialized lock. We also deliver cabinets with iLOQ-readiness and equipped with a latch bolt.

Depending on the space, cabinets can be manufactured with slanted roofs and interior wall cladding. For clean rooms we recommend cabinets manufactured thoroughly with a two-layer structure, where all angular structures are rounded and hence can be cleaned/disinfected by wiping.



Product data sheet

Models	5080 Wall cupboard 5090 Floor cabinet
Materials	Stainless steel AISI 304 (standard) Also available acid-proof steel AISI 316
Standard widths	400, 500, 600 (1-door) 800, 1000, 1200 (2-door)
Standard depths	5080: 350mm 5090: 600mm
Standard lengths	5080: 700mm 5090: 2000mm with legs
Shelf alternatives	Solid plate shelf, perforated plate shelf
Quantity of shelves in standard delivery	5080: 2 pcs 5090: 4 pcs
Height adjustment	50mm increments
Installation	5080: Wall mount 5090: Adjustable legs, wall mount recommended as assurance
Manufacturer	KAVIKA OY, Tempo 4, 04430 Järvenpää, tel. +358 9 8362 0055, kavika@kavika.fi, www.kavika.fi