

### Slop sinks

Slop sink 3180 is a wall-mounted sink with edge flushing that is well-suited for laboratories and for pouring and flushing excretions, small tissue fragments etc. into the drain. The sink is flushed using the push-button tap.

Sinks 3181 and 3182 are mounted on to the sink, work table or fume cupboard top. In addition to mechanical rinsing, a touch-free mechanism can be used.

A slop closet is recommended for flushing larger disposable solid and fluid waste.



#### Technical data

Models	3180 Slop sink 3181 Slop sink mountable on to table, push button rinsing 3182 Slop sink mountable on to table, touch-free rinsing
Material	Acid-proof steel AISI 316
Sink measurements (width x depth x height)	3180 400x400x270 mm 3181 Ø250x300mm 3182 Ø250x300mm
Accessories	3180 hinged grid 3181 removable lid available 3182 removable lid available Plastic trap
Connections	Cold water connection DN15-connection (4,0–8,0 bar pressure) 3180: Drain connection DN70 3181 and 3182: 1 ½ inch external thread
Flush valve	Depending on the model Manual Franke Aqualine AQRM464 Touch-free Franke Protronic AQUA402
Installation	3180 installation height: upper brackets approx. at 900mm (mounting distance 180mm) and lower brackets at 320mm mountable into wall with screws water and drain connections
Manufacturer	KAVIKA OY, Tempo 4, FI-04430 Järvenpää Tel. +358 9 8362 0055, kavika@kavika.fi, www.kavika.fi