

## Gypsum separators 3140

The gypsum separator is made of acid-resistant steel. It is suitable for separating gypsum and other substances heavier than water from water.

The separator is equipped with a water drainage valve, and the lower part of the gypsum separator is easily detachable and can be emptied. The outlet pipe is connected to the floor drain with a separate plastic hose.



### TECHNICAL INFORMATION

Material	Acid-proof steel AISI 316
Measurements	Upper part dimensions: Ø285×110+35 mm drain valve Lower part dimensions: Ø260×215 mm
Accessories included	35 mm drain valve 32 mm outlet pipe faucet Urho latches, 2 pcs
Installation	The separator is installed into the washbasin discharge pipe and mounted with screws onto the wall behind the table. The discharge pipe is connected to the floor drain with a separate plastic hose. The plastic hose is not included in the delivery.
Manufacturer	Kavika HealthCare Oy