

Sink tables 5030/P

Work tables 5030/T

Sink tables and work tables are made of both stainless and acid-proof steel according to their intended use. Eliminating sharp edges and ensuring easy cleaning of surfaces have been emphasized. An elevated rear edge and an edge profile can be fitted in the tables.

Profiles, sinks, fixtures under the sink top and protective hoods can be designed based on intended use.

A manually or electrically operated height-adjustable option of the sink and work table is also available. There is a telescope drain in the sink table. During the design the flexible water connections and the recommendation of 200 mm maximum depth for the basins should be considered.

Sinktops and tabletops can also be delivered separately without a frame.



TECHNICAL INFORMATION

| | |
|--|---|
| Material | Stainless steel AISI 304 Acid-proof steel AISI 316 |
| Frame structure | Galvanised steel plate (standard in sink and work tables) Stainless steel plate Damp resistant chipboard (standard sink and table tops) |
| Base structure | Tubular frame 30x30mm or 40x40mm |
| Standard lengths | 600-4600mm |
| Standard depths | 600-700mm Manual height adjustment 200mm (300mm): minimum depth of table 650mm (750mm) |
| Standard heights | 700-900mm |
| Height-adjustable tables | Height adjustment range 300 mm or 200mm |
| Accessories included | Sink tables: edge profile, a base valve and a rubber plug In height-adjustable sink tables also a telescope stretch trap available |
| Accessories | Sinks (maximum depth 200mm on the height adjustment table) Sink cabinets Scent locks Shelves (flat, grid, perforated plate) Waste cabinets Cabinets Slop sinks Height adjustment (manual or electric) Corner tables and corner rounding Drawers Notches Cover plate Raised rear edge Draft protection hood |
| Connections | Water and drain connections Electrical outlet in height-adjustable table |
| Standards and directives in electric height-adjustable table structures taken into account | EN 60204-1 Safety of machinery ISO 12100:2010 Safety of machinery Low Voltage Directive 2014/35/EU EMC Directive 2014/30/EU Machinery Directive 2006/42/EU |
| Installation | Adjustable feet Wall mounting, adjustable feet in front (cleaning space between the table and the wall) |
| Manufacturer | Kavika HealthCare Oy |