

## Slop sinks 3180 / 3181 / 3182

Slop sink 3180 is a wall-mounted sink with edge flushing that is well-suited for laboratories and for pouring and flushing excretions, small tissue fragments etc. into the drain. The sink is flushed using the push-button tap.

Sinks 3181 and 3182 are mounted on to the sink, work table or fume cupboard top. In addition to mechanical rinsing, a touch-free mechanism can be used.

A slop closet is recommended for flushing larger disposable solid and fluid waste.



## TECHNICAL INFORMATION

Models	3180 Slop sink, push button rinsing 3181 Slop sink mountable on to table, push button rinsing 3182 Slop sink mountable on to table, touch-free rinsing
Material	Acid-proof steel AISI 316
Sink measurements (width x depth x height)	3180 400x400x270 mm 3181 Ø250x300mm 3182 Ø250x300mm
Accessories included	Plastic trap 3180 hinged grid
Accessories	3181 removable lid 3182 removable lid
Connections	Cold water connection DN15-connection (1,0–4,0 bar pressure) 3180: Drain connection DN70 3181 and 3182: 1 ½ inch external thread
Flush valve	Depending on the model Manual Franke Aqualine AQRM464 Touch-free Franke Protronic AQUA402
Installation	3180 installation height: upper brackets (2 pc) approx. at 900mm (mounting distance 180mm) and lower brackets at 320mm mountable into wall with screws water and drain connections
Manufacturer	Kavika HealthCare Oy