

## Pass through hatches for clothing

A stainless steel pass through hatch for clothing improves hygiene and logistics in the textile maintenance of a hospital or institution.

The clothes pass through hatch is suitable for transferring dirty textiles from the dressing room to the textile maintenance. A through hatch is installed in the dressing room and in the maintenance room there is a shaft on the other side of the wall from which the textiles fall into a collection container or bag.

The clothes pass through hatch consists of two parts, which are inserted into each other on both sides of the wall and sealed shut during installation. The door can be opened and closed according to the space. The door can be equipped with seals to improve sound and air insulation.



### TECHNICAL INFORMATION

Models	Pass through hatch for clothing 6100 door opening left or right
Material	Stainless steel AISI 304 (standard) Acidproof steel AISI 316 (available)
Measurements	300x500x300 mm, mounting frame 50-150 mm Can be made to tailored dimensions
Accessories	Door sealing Latch lock
Installation	Wall mounting with mounting compound
Manufacturer	Kavika HealthCare Oy