

Sink tables for cleanroom

In the cleanroom product range you will find high-quality solutions for cleanroom furniture.

Cleanroom sink tables are made of stainless steel according to the customer's measurements. The cleanroom tables are designed with attention to the cleanability of the product.

The table base furniture has a uniform, seamless interior wall cladding with rounded corners. There are no structures inside the furniture where contaminants could hide. The drawer units have lift-out drawers and tool-free removable rails.



Sink table 6030 with L4-drawer and sink cabinet

TECHNICAL INFORMATION

Models	Sink table cleanroom 6030
Material	Stainless steel AISI 304 (standard) Acidproof steel AISI 316 (available)
Measurements	Leghts: starting from 600 mm Depth: 600-700 mm Height: 700-900 mm Height-adjustment: stroke 200-400 mm, Ergoswiss
Accessories	Sink with bottom valve and rubber plug Height-adjustable sink table with telescopic drain
Optional accessories	Sink cabinet: left-, right- and two-handed Lower cabinet: left-, right- and two-handed Drawers: L1-L4 with removable container (Gastronorm-sizing) Shelves: standard, perforated Plinth cover plate Stop sink Water traps
Connections	Water and drain connections Electrical outlet for height-adjustable desk
Standards and directives in electric height-adjustable table structures taken into account	EN 60204-1 Safety of machinery ISO 12100:2010 Safety of machinery Low Voltage Directive 2014/35/EU EMC Directive 2014/30/EU Machinery Directive 2006/42/EU
Installation	Adjustable feet Plinth flush with the floor
Manufacturer	Kavika HealthCare Oy