

Wall cabinets and Floor cabinets for cleanroom

In the cleanroom product range you will find high-quality solutions for cleanroom furnishing.

Wall and floor cabinets for cleanrooms are made of stainless steel according to the customer's measurements. The most common dimensions can be found in the technical data.

The cabinets have a sloping roof on the outside. Inside the cabinets there is an interior wall cladding with rounded corners. There are no structures inside the cabinet where contaminants could hide. The shelves are height-adjustable using hygienic shelf pins inside the cabinet. The shelves are available as flat and perforated sheet shelves. The cabinet doors are made of two sheets by welding and grinding all the way through, resulting in a seamless double door structure.



TECHNICAL INFORMATION

Models	Wall cabinet for cleanroom 6080 Floor cabinet for cleanroom 6090
Material	Stainless steel AISI 304 (standard) Acidproof steel AISI 316 (available)
Measurements	Width: left and right-handed 600 mm, two-door 1200 mm Height: wall cabinet 700/900 mm, floor cabinet 2000/2200 mm Depth: wall cabinet 350 mm, floor cabinet 600 mm Can be made to special dimensions
Accessories	6080: two shelves 6090: four shelves Slanted roof Rounded corners inside the cabinet Floor cabinet with adjustable feet
Optional accessories	Glass doors with stainless steel frame Perforated shelves
Installation	Wall cabinet: wall mounting with screws Floor cabinet to be straightened with adjustable feet, wall mounting recommended with installation mass and silicone The fasteners and adhesives used for installation are not included in the delivery.
Manufacturer	Kavika HealthCare Oy