

Wall shelves and Floor shelves for cleanroom

In the Cleanroom product range you will find high-quality solutions for cleanroom furniture. Wall and floor shelves are made of stainless steel according to the customer's measurements, within the dimensions specified in the technical data.

The structure of the shelves is designed to facilitate cleaning of the product.

The cleanroom wall shelf 6020 is manufactured as a single shelf module, which can be grouped to create the required shelf assembly.

The floor shelf 6040 has fixed shelves welded to the frame. Cleanroom shelves are available as flat shelves or perforated plates.



Wall shelf 6020



Floor shelf 6040 with perforated shelf levels

TECHNICAL INFORMATION

Models	Wall shelf 6020 Floor shelf 6040
Material	Stainless steel AISI 304 (standard) Acidproof steel AISI 316 (available)
Measurements	Wall shelf: Width 300-1000 mm, Depth 150-350 mm Height 150 mm Floor shelf: Leveys 500-1200 mm Depth 500 mm Height 2000 mm
Accessories	6020: one level 6040: to be delivered fully assembled five fixed shelves adjustable feet wall mounts 2 pcs
Optional accessories	perforated shelf levels
Installation	Wall mounting Wall mounting also recommended for floor shelf Floor shelf straightened with adjustable feet
Manufacturer	Kavika HealthCare Oy